

# Instructions: Installation of a Wall Anchor

## Instructions:

1. Position the wall anchor at the desired location on the wall and mark out holes with a pencil. (We recommend installing the wall anchor at a height of 50cm measured from the bottom of the anchor to the ground)

If installed on brick work, position the anchor so that the bolt holes will be drilled in the middle of the brick, not in the brick joints.

2. Drill 4 x holes deep enough to fit the sleeve anchor.

3. Take sleeve anchors apart, and attach and reassemble all four sleeve anchors to the back of the wall anchor. Make sure you do not tighten the sleeve anchors as it will cause them to expand.

4. Insert the wall anchor with the sleeve anchors in to the holes, making sure the bicycle logo is oriented the right way up. Tap the wall anchor gently until it is flush against the wall.

5. Use the allen key to tighten up the sleeve anchors to secure the bracket.

6. If you require the bolts to be permanently installed, hammer the ball bearings into the hex hole of two diagonally opposed bolts. (Note: the bolts can no longer be undone. To remove use an angle grinder to cut the ball bearing out so that the allen hole can be accessed)



### Parts included:

- Cyclehoop Wall Anchor
- Sleeve anchors x 4
- Ball bearings x 2

### Tools required:

- Electric drill with 10mm drill bit
- Pencil
- Allen key
- Hammer